SPECIFICATION

Receiver

Receive mode	crystal frequence lock
frequence stability	15PPM
sensitivity	3uV 30dB S/N
signal to noise ratio	60dB
audio output	0~0.5V/4.7h
power	AC120(±10%)
Transmitter	
frequence stability	15PPM
modulate mode	FM
modulate degree	>30KHz
emission power	30mV MAX
harmonic suppression	40dB
battery	1.5V AAbattery
System specification	
frequence stability	±0.005%
modulate mode	
frequence response	50-16000Hz
signal to noise ratio	>60dB
maximum sound pressure	≥120dB
distortion factor	≤1%

WIRELESS MICROPHONE SYSTEM

MARTIN RANGER UHF 700



- To be sure you take maximum advantage of the features, read this manual carefully before use.
- For purposes of improvement, specifications and design are subject to change without notice.
- This manual has been checked carefully, if any mistakes because of printing or other reason make you puzzle, please call the dealer.

OWNER'S MANUAL

PREFACE

Thank you for buying our excellent wireless microphone series products. Before you use our products, please read this Owner's Manual, so that you can enjoy it. Keep this manual in a safety place for your future references.

This series professional wireless microphone system introduces a number of advanced technology and components, including the efficient low-consumption RF transmission technology, elimination of switching impact technology, slow changed output control technology, superb sensitive VHF narrowband receiver and etc..

EDA, online simulation accessorial design and strict quality control are applied to ensure each system with excellent electronic function.

Features:

- Desktop receiver and enhanced muting, high signal / noise ratio.
- Almost zero noise output when standby.
- Broad frequency response range, super low distortion.
- No impact on switching receiver, ensure safety of rear stage amplifier system and speaker.
- Perfect operative status signals, fluorescence display, with digital microphone.
- Long practical distance. Over 30 m in ideal circumstances; practical 20 m radius in complex circumstances.
- Dual frequency design. Be able to use two microphones at the same time without mutual interference.
- Applicable for medium& small stages, karaoke halls, and home entertainment etc.


Matters Needing Attention:

- Be sure to check whether the local voltage accord with operative voltage of the microphone before using, make correct selection. (Wrong selection may lead to burnout of the whole machine.)
- 2. Please don't open or dismantle the machine on your own. For internal repair, please contact the local distributor or accepted service center.
- 3. When the machine will not be used for a long time, please pull the power plug out of AC power socket.


Cleaning:


- 1. Please make sure to cut off the power before repairing or cleaning this machine.
- 2. The machine can be cleaned by soft cloth. To clean off stiff dirt, please use dry cloth dipping with neutral wash; clean the machine with dry cloth then.
- 3. Please don 't use volatile gasoline, diluents or other chemicals for the machine body, or the surface will be corrupted.

RECEIVER



RECEIVER FRONT PANEL SKETCH





- 1. Power on/off switch
- 2. Channel A volume control knob
- 3. Display
- 4. Channel B volume control knob
- 5. Channel B antenna
- 6. Audio output jack
- 7. Power input
- 8. Channel A antenna
- 9. Channel A signal lamp
- 10. Channel B signal lamp
- 11. Channel A charge indicator lamp
- 12. Channel B charge indicator lamp

TRANSMITTER

ANTENNA


Fully pull out antennas 5 and 8; adjust the antennas to be perpendicular to the floor Antenna installation will directly affect the receiving effect.

INSTALLATION AND USE

- Better keep distances between the receiver and wall & floor to ensure good receiving signals.
- 2. Don't put the receiver beside digital control equipments.
- Connect the receiver and tuner or corresponding amplifier inlet with audio transmission cables, adjust the corresponding signal channel volume knob to get suitable audio output.
- 4. Switch the power to your local operating voltage; insert the power plug into the power socket.
- 5. Switch on the power, display 3 will light up. Adjust volume knobs 2.4 to the least.

HAND-HOLD MICROPHONE

- Cartridge module
- Mic body
- 3. Operating indicator
- Power switch
- Battery cover




INSTALLATION AND USE

- Open the battery cover 5,1.5V AA batteries for microphone. Pay attention to the positive and negative pole signs of the batteries.
- 2. Position the power switch to ON, indicator light 3 will be on, and indicator 10 or 15 on the receiver display will be on, showing (), corresponding operating frequency point 12 or 13 will also be on synchronously, indicating the receiver is receiving effective signals from the microphone.
- Position the audio switch to ON, make voices toward the microphone and adjust receiver volume control knobs 2 and 4, volume control display 9 and 15 will be on, indicating the volume you are adjusting, at the same time AF LEVEL display 9 or 15 will dance with the music.
- When the power indicator darkens, it indicates lack of power. Please change with new batteries in time.
- 5. To make your singing more perfect, please keep the distance between microphone and sound source as 3-5cm.

TRANSMITTER

LAVALIER BODYPACK TRANSMITTER



- Open the batter cover, put in 9V overlapped batteries. Pay attention to the positive and negative pole signs of the batteries.
- 2. Insert the transmitter cable and cartridge module to the cartridge socket.
- 3. Position the power switch to ON, indicator light will be on, and indicator 9 or 16 on the receiver display will be on, showing(), corresponding operating frequency point 10 or 15 will also be on synchronously, indicating the receiver is receiving effective signals from the microphone.
- 4. Make voices toward the microphone, adjust receiver volume control knobs 2 and 4, volume control display 11 and 14 will be on, indicating the volume you are adjusting, at the same time AF LEVEL display 12 or 13 will dance with the music.
- When the power indicator darkens, it indicates lack of power. Please change with new batteries in time.

CHANGING BETTERIES

- 1. The transmitter must be switched off before changing batteries.
- 2. If the transmitter will not be used for a long time, please take outbatteries to avoid the parts of transmitter being destroyed by rotten batteries.

PREPARATION BEFORE SOUND TESTING

- Make sure the frequencies of transmitter and receiver conform to each other.
- 2. Keep the distance between antenna and transmitter over 1 meter.
- 3. Avoid whistling, especially when using the omnidirectional microphone.

OUR SUGGESTIONS:

- Decrease the system volume.
- Keep the transmitter away from the speakers.
- Tune down cartridge sensitivity of the transmitter.

TROUBLESHOOTING

Receiver

Problem	Possible cause	solution
Fail to operate	 Poor connecting of the receiver power or the power isn't correct 	Check the operation power correct or not and plug it securely
No receive	 The transmitter is out of the effective range The frequence of the transmitter and the receiver isn't same The antenna hasn't be pull out 	 Operating it in the effective range Set the frequence to same Pull out the antenna
Distorted sound	The volume of microphone is too loud	reduce the volume of the microphone

Transmitter

Problem	Possible cause	solution
Fail to operate	 The battery voltage isn't enough The battery install isn't correct polarity 	Replace the batteries Install the batteries correctly
No carrier signal	 The transmitter is working out of effective field The frequence of the transmitter and the receiver isn't same 	Operating it in effective fieldSet the frequence to same
Noise and distorted sound	 Disturb by other electric wave The operation frequence of two transmitter is same. The batteries voltage of the transmitter isn't enough. 	Shorten the operation distance of the transmitter and the receiver Move the receiver far away interference. The same operation frequence of two transmitter should be avoid. Replace the batteries.

ATTENTION _____

For the rechargeable system, which uses AA recycle rechargeable batteries. It has recharge equipment. The recharge instructions are as below:

- When the handheld microphone is out of power during using, please recharge it in time.
- Plug in the receiver, screw out antenna of the microphone. and connect the microphone into the recharge socket on top of the receiver. the recharge signal When the batteries are recharged.
- 3. In recharge status, the receiver will automatically close its display and audio output.

Special Warning:

This charger is applicable for AArecycle rechargeable batteries only. Non-rechargeable batteries are forbidden to be used to avoid any danger.

Application:

- 1. Applicable batteries: AA1.5V rechargeable batteries.
- 2. Rated recharge power:100mA+/-10%
- 3. Rated recharge time: > 4hrs.

Hold The Transmitter With Care:

- Please don't letany objects (dust, raindrop, grit) fall intoth e machine to cause any damage to it.
- Please avoid the machine falling onto the ground. Keep it away from serious strike or shake
- The machine is not waterproof. Please avoid raindrop, tea etc. splattering onto the machine.

Ensuring:

Should this machine does not work as usual, please stop using, takeout the batteries or cut off the AC powerimmediately. Please contact the local distributor or accepted service center to ensure your effective rights and interests.

Permission:

In most countries of the world, regulations for wireless systemare generally stipulated by the governments. To get legal usage permission is a must. The local distributors may give you regulations for wireless system in your district.